

HORIBA

ONLINE GAS ANALYZER

fdg

TECHNICAL MANUAL CEM500



HORIBA ADVANCED TECHNOLOGY FRANCE

100B ALLÉE DE ST EXUPÉRY – 38330 MONTBONNOT ST MARTIN – FRANCE

TEL : +33 4 76 41 86 39 – FAX : +33 4 76 41 92 27

MAIL : SALES.HATFR@HORIBA.COM -WEB : WWW.HORIBA.COM

Safety warning and liability



Chemicals used as reagent or used as cleaning solution or used to prepare calibration solutions might be toxic, corrosive or irritant. Refer to the material safety data sheets (MSDS) for each chemical. Wear protection glass and gloves.



The documentation and/or Product are provided on an “as is” basis only and may contain deficiencies or inadequacies. The Documentation and/or Product are provided without warranty of any kind, express or implied.

The manufacturer or its suppliers shall, regardless of any legal theory upon which the claim is based, not be liable for any consequential, incidental, direct, indirect, punitive or other damages whatsoever (including, without limitation, damages for loss of business profits, business interruption, loss of business information or data, or other pecuniary loss) arising out the use of or inability to use the Documentation and/or Product, even if the manufacturer or its suppliers has been advised of the possibility of such damages.



This equipment meets the requirements of all relevant European safety directives. The equipment carries the CE mark.

**To prevent electric shock:**

- Unplug the power cord before any servicing, wiring or any operation inside the instrument.
- Connect this instrument only at a properly grounded power socket.
- Keep the screws well tight.



No. 5019

This instrument must be earthed!

In order to prevent any electric shock, verify that the power socket used for this instrument has an earth connection in accordance with regulations.



The security provided by this product is only assured for the intended use.

Maintenance can only be performed by qualified personnel.



Do not dispose of this product as household waste. Use an approved organization that collects and/or recycles waste electrical and electronic equipment.

CONTENTS

| | | |
|-------------|--|-----------|
| 1. | Maintenance Schedule..... | 6 |
| 2. | Procedures | 7 |
| 2.1. | Maintenance Procedures for the Gas Circuit..... | 7 |
| 2.1.1. | How to Change the Internal Membrane Pump | 7 |
| 2.1.2. | How to Check the Solenoid Valve | 10 |
| 2.1.3. | How to Check / Recalibrate the Pressure Sensor | 11 |
| 2.1.4. | How to Check / Calibrate the Flow Rate..... | 13 |
| 2.2. | Maintenance Procedures for Optics and Flow Cell | 14 |
| 2.2.1. | How to Set the Signal Intensity..... | 14 |
| 2.2.2. | How to Clean the Quartz Disks of The Flow Cell..... | 15 |
| 2.2.3. | How to Change the Xenon Block Lamp..... | 17 |
| 2.2.4. | Calibration of Spectrograph..... | 18 |
| 2.3. | How to Add / Remove a Gas | 20 |
| 2.3.1. | How to Add a Gas | 20 |
| 2.3.2. | How to Remove a Gas | 20 |
| 2.4. | Memory Re-initialization | 21 |
| 2.5. | USB..... | 22 |
| 2.5.1. | How to Take Screenshots | 22 |
| 2.5.2. | How to Update the Software..... | 22 |
| 2.6. | Boards Synoptics | 23 |
| 2.6.1. | DSP500..... | 23 |
| 2.6.2. | XENON500..... | 29 |
| 2.6.3. | OUT-4-20-500 | 30 |
| 2.6.4. | IN-4-20-500 | 31 |
| 2.6.5. | RELAY500..... | 32 |
| 2.7. | Modbus Addresses | 33 |
| 3. | Troubleshooting..... | 36 |
| 3.1. | General Troubleshooting..... | 36 |

| | | |
|------|--------------------------------------|----|
| 3.2. | Measurements troubleshooting | 37 |
| 3.3. | Measuring Errors for Parameters..... | 38 |
| 4. | General Specifications..... | 39 |

1. Maintenance Schedule

The maintenance of the CEM500 analyser is limited to the replacement of spare parts such as the lamp block after one year if used in continuous mode, and to the replacement of the membrane of the sampling pump (optional).

The maintenance schedule of spare-parts is detailed in **Table 1**.

Table 1. Maintenance schedule

| Spare part | Reference | Frequency of replacement |
|---|---------------|---|
| Xenon lamp block | E-XEN-G-1 | Given for 10 ⁹ flashes (3 years of lifetime in continuous mode) |
| Internal membrane pump with heated head | MKIT-SPL- G-1 | Every year |

In rare cases, there might be exceptional maintenance, depending on the use of the analyser (refer to **Table 2**).

Table 2. Exceptional maintenance

| Spare part | Reference | Frequency of replacement |
|--|-----------|------------------------------------|
| Lens (diameter 12 mm) with one O-ring | O-LENS-1 | 3 to 10 years depending on the use |
| Disk (diameter 12 mm) with three O-rings | O-DISK-G | 3 to 10 years depending on the use |

2. Procedures

2.1. Maintenance Procedures for the Gas Circuit

2.1.1. How to Change the Internal Membrane Pump


The sampling pump is optional.

The head of the pump is heated with the rest of the gas circuit and has a flow rate of about 6 L/min. If the pump runs continuously, the membrane must be changed once per year.


Procedure to check the head of peristaltic sampling pump

To check if the head of the peristaltic sampling pump needs to be changed, proceed as follows:

- a. Put the analyser in stopped mode in the Timing screen shown below:



- b. Disconnect any outlet tubing from the analyser.
- c. Connect the outlet to a flow meter (0 - 10 L/min, preferentially a ball model) to the zero inlet of the analyser. Leave the inlet of the flow meter free on ambient air.
- d. On the Factory screen, go to the "Outputs 24 VDC" and press on OFF below the "Sampling pump", as shown on the following screenshot.



A strong noise must be heard when the pump is running. If not, check the electrical connections of the pump.

The flow meter must indicate a flow rate of about 6 L/min. If lower than 4 L/min, change the membrane of the pump.

Procedure to change the internal membrane of peristaltic sampling pump

The following figure shows the different elements of the peristaltic sampling pump and their assembly order:




Fig. 1





Fig. 3,
Disposition des rondelles



To change the membrane of the peristaltic sampling pump, the following tools and materials are required:

- Fork wrench or socket wrench 5.5mm
- Pin-wrench for two-hole nuts, pin diameter 4mm
- Holding tool
- Heat-resistant thread adhesive

To change the membrane of the peristaltic sampling pump, proceed as follows:

a. **Preparatory step**

Disconnect the pump from the power supply. Check that the pump is electrically dead and secure this.

b. **Removing pump head**

- Mark the position of the carrier (1), intermediate plate (3), and head plate (4) relative to each other by a drawing line (M) with a felt-tip marker. This is to ensure that the parts will be reassembled in the correct position at a later stage.
 - Release the nuts (6) and remove them together with the disk springs (5).
 - ⇒ The disk spring are fitted in order to maintain the tension of the wave diaphragm right across the temperature range of the pump.
 - Remove head plate (4).
 - Remove o'ring (10) from head plate (4).
 - Remove the valve plate (11) and the intermediate plate (3).
- c. **Changing diaphragm**
- Release the retainer plate (7) by turning it anti-clockwise with a pin wrench or a wrench for retainer plate. While doing so, hold the connecting rod extension (9) in place with holding tool.

Take care to ensure that the washer (12) does not slip under the diaphragm support (8).

- Remove wave diaphragm (2).
 - Check that all parts are free from dirt and clean them if necessary.
 - Slide a new wave diaphragm (2) onto the threaded bolt of the retainer plate (7).
 - ⇒ The wave diaphragm assembly consists of two equivalent parts placed on top of one another; the top and bottom are identical.
 - Apply a small amount of heat-resistant thread adhesive to the thread of the retainer plate (7).
 - Screw the retainer plate (7) with wave diaphragm (2) into the connecting rod extension (9); to tighten the retainer plate, use the wrench for retainer plate/the pin wrench to turn it clockwise (torque: 4.6Nm). While doing so, hold the connecting rod extension (9) in place with the holding tool; and hold the wave diaphragms so that they do not twist.
- d. **Changing valve plate and sealing ring**
- Check that intermediate plate and head plate are clean. If damages, distortion, or corrosion are evident on these parts they should be replaced.
 - Place the intermediate plate (3) on the carrier (1) in the position indicated by the felt tip pen mark (M).
 - Lay the new valve plate (11) onto the intermediate plate (3).
 - ⇒ Regarding the placement of the valve plate: The notch on outer edge of the valve plate must be at the left rear, when looking at the pump from the motor.
 - Fit the new o'ring (10) in the head plate (4).
- e. **Refitting pump head**

- Place the head plate (4) on the intermediate plate (3) in the positions indicated by the felt-tip pen marking.
 - Place disk spring (5).
 - Put the nuts (6) in place and tighten them diagonally, until each of them lies level on the top spring washer; realign the pump head. From when you start applying pressure on the disk springs, tighten the nuts through an angle of 340° . That is equivalent to a torque of 80Ncm.
- f. **Final step**
- Reconnect the pump to the electricity supply.

2.1.2. How to Check the Solenoid Valve


The main element of the gas circuit is the 3-way solenoid valve represented below that selects the zero air (deactivated) or the sample (activated) to the measuring flow cell.

In stopped mode, the solenoid valve stays deactivated to the zero air.

If the gas circuit has not reached the temperature setting point (with a tolerance of 10°C), the solenoid valve stays on the zero-air inlet to prevent humid and dirty sample to enter in the cold flow cell that may produce condensation and deposits.

To check the solenoid valve, proceed as follows:

- a. Disconnect the sample line.
- b. Put the analyser in stopped mode in the Timing screen.




- c. Connect a flow meter (preferentially ball model) on an air cylinder or small air pump to get a flow rate of about 2 L/min.
- d. Connect the outlet of the flow meter to the zero inlet and check that the flow rate stays roughly unchanged around 2 L/min.
- e. On the Factory screen, go to the "Outputs 24 VDC" and press on OFF below the "EV sample", as shown below.

A strong sound "click" must be heard just when pressing on the OFF key. If not, check the solenoid valve connection on the DSP500 board.

The flow meter must immediately go down to a null flow. A small flow rate remaining may indicate a

leakage on the zero circuit or inside the solenoid valve.

- f. Now connect the flow meter outlet to the sample inlet and check that the flow rate goes up again to roughly 2 L/min (go back to the previous screen if expired).



A strong sound "click" must be heard again just when pressing on the ON key.

The flow meter must immediately go down to a null flow. A small flow rate remaining may indicate a leakage on the inlet circuit or inside the solenoid valve.

2.1.3. How to Check / Recalibrate the Pressure Sensor


The pressure probe is used for two reasons:

- To automatically compensate the gas pressure (above or under the atmospheric pressure) as the measurement is directly affected by over / under pressure.
- To give a flow rate indication. This flow rate must be calibrated according to the outlet circuit if a good accuracy is needed, but this will not affect the measurements.

If the sampling pump is placed before the flow cell (recommended configuration), the pressure during measurements is always above the atmospheric pressure. With an outlet going to the atmospheric pressure (recommended) the over pressure generally stays below 5 to 10 mbar, generating a very small pressure compensation.

To check or recalibrate the pressure probe, proceed as follows:

- Disconnect any tubing from the back of the analyser.
- Put the analyser in stopped mode in the Timing screen.



- On the Process screen, press anywhere highlighted by the red. This opens a new screen for temperature, pressure and flow rate.



- Press on the zero key. The relative pressure must go down to zero hPa.
- Connect a pressure meter (range 0 - 1 bar) on the gas outlet.
- Connect an air cylinder on the zero inlet and adjust the regulator to 0.5 bar (note: a small membrane pump can be used instead of the air cylinder).
- Read the pressure on the pressure meter and compare it to the displayed relative pressure.
- In case of minor difference, the pressure factor can be readjusted to get the right value.
- In case of no response or incoherent response, the pressure sensor must be changed.

2.1.4. How to Check / Calibrate the Flow Rate

To check and / or calibrate the flow rate, proceed as follows:

- Keep the analyser is stopped mode as explained before and make sure that the pressure reading is zero (inlets out outlet free).
- Insert a mass flow meter or ball flow meter (range 0 - 10 L/min) between an air cylinder and the zero inlet.
- Adjust the regulator of the air cylinder to get a flow rate of about 1 L/min.
- On the Process screen, press anywhere highlighted by the red. This opens a new screen for temperature, pressure and flow rate.




- Adjust the flow factor proportionally to get the same flow rate reading than the flow meter.

2.2. Maintenance Procedures for Optics and Flow Cell


2.2.1. How to Set the Signal Intensity

The intensity of the signal can be monitored and changed. To do so, proceed as follows:


- Put the analyser in stopped mode in the Timing screen.



- Go to the Check screen and select the signal button. This button displays the lamp spectrum obtained after the last measuring cycle, as shown below:



- c. The intensity of the signal can be modified by playing on the screw of the lamp block, as shown below. First, untight the M4 nut. Then untight the screw as much as possible.



- d. Once untighted, press PLAY on the screen displaying the lamp spectrum.
- e. By tightening the screw, you can follow the evolution of the intensity of the signal on the screen.
- f. The signal requirements depending on the wavelengths are:
- the more intense peak at 229 nm (aligned on the red reference line) should be between 1400 and 1600 mV.
 - The peak at 200 nm should have a signal of about 200 mV.
- g. Once the signal is meeting the previous requirements, tight the M4 nut while making sure the M4 x 12 screw does not move. The lamp is now well aligned and will not move.
- h. Go back to the lamp screen and adjust for number of flashes to get a signal of about 200 mV at 200 nm.

The lamp alignment is necessary after a change of lamp.


2.2.2. How to Clean the Quartz Disks of The Flow Cell

The two quartz windows of the flow cell may have to be cleaned in case of abnormal operation like insufficient heating, abnormal level of dust or particles in the sample gas.


They may have to be replaced after a long operating time (over years of continuous operation) in case the transparency has decreased due to UV irradiation.

To clean the flow cell windows, proceed as follows:


- a. Make sure the power cord is disconnected.
- b. Unscrew the four knurled knob maintaining the cover of the heated compartment and remove the cover.
- c. If necessary, wait for the heated parts to cool down to ambient temperature to avoid any burning during manipulations.
- d. Unscrew the three fitting nuts of the flow cell to remove the tubing as shown in the following figure:



- e. Unscrew the four M4x25 screws of the flow cell as shown below:



- f. Unscrew the four screws maintaining the extensions on each side of the flow cell as shown below:



- g. The disks can be cleaned with a soft tissue imbided of alcohol. If they remain dirty, you can soak them (and the absorption flow cell) in a 5% sulfuric acid H_2SO_4 solution for about 30 minutes. Then take them out and dry them with a soft tissue. If the disks are not totally clear

after cleaning, replacing them is recommended. It is also recommended to change the O-rings if the geometry is affected. Only use O-rings provided by the manufacturer.

Once all elements are clean and dry, assemble the flow cell as indicated in the previous picture:


- Be careful to dry the O-ring before putting them back.
- Place the absorption flow cell back in the CEM500 enclosure using four M4x25 screws.
- Check the signal.

2.2.3. How to Change the Xenon Block Lamp


As for the quartz windows of the flow cell, the quartz lens can be damaged by the UV irradiation after a long time of exposure (over three years of continuous operation).

To clean or replace the lens from the lamp block, proceed as follows:

- Turn off the analyser.
- Unscrew the four screws of the lamp block as shown below and disconnect the lamp connector.



- Unscrew the four screws maintaining the lens as shown below:



- The lens can be cleaned with a soft tissue imbibed of alcohol. If the lens is not totally clear after cleaning, it must be replaced.
- Reassemble following the reversed order and check the light level (refer to section 2.2.1).

2.2.4. Calibration of Spectrograph




Never neither try to open the spectrograph nor to clean the grating. The grating will be immediately destroyed by the contact to any tissue, even very soft.


The spectrograph might need to be recalibrated in case of replacement or software update.

To calibrate the spectrograph, proceed as follows:

- Cycle some air several times to make sure the gas circuit and flow cell are cleaned.
- Go on the Check screen:



- Select the signal button. This button displays the lamp spectrum obtained after the last measuring cycle, as shown below:



- d. On the Check screen, refer to the two wavelength bands used for the absorbance calculation defined as “Peak wavelength” and “Ref wavelength”. Check that the signal are not saturated (around 2000 mV). If yes, an error will occur during the measurements.
The values can be read by moving the cursor with the vertical arrows. If necessary, use the horizontal arrows to displace the graph or press on the graph to zoom it. The Y scale is automatic but may be override by the small arrows placed above the Y axis.
- e. Press on “CALIBRATION” on the left side of the screen. The four main peaks will automatically match the four red lines.
- f. If not, you can manually calibrate the spectrograph by unticking “Auto calibration” and adjusting the “Lambda start” wavelength.

2.3. How to Add / Remove a Gas


2.3.1. How to Add a Gas

The CEM500 analyser is made for one gas, including gas declaration, linearity, compensations (offsets and gains) and an output 4-20 mA module.

Any additional gas requires an extra cost to include complete calibration and output 4-20 mA.

In case you need to declare a new parameter, proceed as follows:

- a. In the Factory screen, select <NEW> on the frame called “List of parameters”.



- b. Select the parameter you want in the list and click on the green arrow.
- c. Enter the password to be able to add the gas.
- d. The following screen is about MULTIPLEXING and the number of streams, if any.
- e. The last screen is about the positions of 4-20 mA output modules.

The parameter is now added to the list on the frame called “List of parameters”.

2.3.2. How to Remove a Gas

In case you need to remove a parameter, proceed as follows:

- a. On the Factory screen, click on the parameter you wish to delete on the frame called “List of parameters”.
- b. A window will appear, to confirm the erasing of the parameter. Click on the green arrow.


The parameter will be deleted from the list on the frame called “List of parameters”.

2.4. Memory Re-initialization

This procedure erases all the configuration (channel, parameters, general settings...). It may be exceptionally used in case of board replacement. The configuration must then be reintroduced either manually or from a configuration file saved on a USB key.

To do a memory re-initialization, you must be logged as administrator by using the password 7895. Then, proceed as follows:

- In the Factory screen, select ERASE on the “Configuration” frame.
- Note that you can select SAVE before doing the re-initialization. It will save the configuration on a USB key. This configuration back-up includes: the gas channels with their linearity and compensation tables (offsets and gains).




2.5. USB

2.5.1. How to Take Screenshots

To take screenshots, proceed as follows:

- a. Go on the Communication screen.



- b. Select ON at the top left of this screen.

From now on, a screenshot will be saved on your USB key when you insert it in the USB plug on the CEM500 enclosure. This configuration will last for 1 hour. Then, do this procedure again to reactivate the USB screen copy.

2.5.2. How to Update the Software


In case you need to update the software, proceed as follows:

- a. On one hand, on the analyser: save the configuration (in the factory screen) on a USB key.
- b. On the other hand, save the software file on this USB key.
- c. Turn off the analyser.
- d. Plug in the USB key on the analyser.
- e. Turn on the analyser.
- f. Choose the version of software you want to download and press on START.
- g. Once the downloading is finished, remove the USB stick.
- h. On the factory screen, you can load the configuration again. You can then start using the analyser.


2.6. Boards Synoptics

2.6.1. DSP500


DSP500 schematics 1/6
Release B




DSP500 schematics 2/6
Release B



DSP500 schematics 3/6
Release B



DSP500 schematics 4/6
Release B



| Connector J10 | |
|---------------|--------|
| pin | Signal |
| 1 | +ch3 |
| 2 | +ch2 |
| 3 | +ch1 |
| 4 | -ch1 |
| 5 | -ch2 |
| 6 | -ch3 |


| Connector J9 | |
|--------------|--------|
| pin | Signal |
| 1 | Bottom |
| 2 | Left |
| 3 | Top |
| 4 | Right |

| Connector J8 (continued) | |
|--------------------------|--------|
| pin | Signal |
| 24 | B4 |
| 25 | B5 |
| 26 | GND |
| 27 | ENAB |
| 28 | VCC |
| 29 | VCC |
| 30 | R/L |
| 31 | U/D |

| Connector J8 | |
|--------------|--------|
| pin | Signal |
| 1 | GND |
| 2 | CK |
| 3 | H sync |
| 4 | V sync |
| 5 | GND |
| 6 | R0 |
| 7 | R1 |
| 8 | R2 |
| 9 | R3 |
| 10 | R4 |
| 11 | R5 |
| 12 | GND |
| 13 | G0 |
| 14 | G1 |
| 15 | G2 |
| 16 | G3 |
| 17 | G4 |
| 18 | G5 |
| 19 | GND |
| 20 | B0 |
| 21 | B1 |
| 22 | B2 |
| 23 | B3 |

DSP500 schematics 5/6

Release B




| Connector J35 to J46 | |
|----------------------|--------|
| pin | Signal |
| 1 | GND |
| 2 | CS |
| 3 | DIN/ |
| 4 | SCLK/ |
| 5 | DOUT |
| 6 | +3.3V |
| 7 | 0VP |
| 8 | +24V |
| 9 | +12V |

| Connector J20 | |
|---------------|--------|
| pin | Signal |
| 1 | +24V |
| 2 | +3.3V |
| 3 | P1V |
| 4 | P1H |
| 5 | P2V |
| 6 | P2H |
| 7 | RG |
| 8 | CE/ |
| 9 | CLK+ |
| 10 | CLK- |
| 11 | DIN+ |
| 12 | DIN- |
| 13 | DOUT+ |
| 14 | DOUT- |
| 15 | GND |
| 16 | GND |

DSP500 schematics 6/6

Release B




| Connector J17, J18, J19 | |
|-------------------------|--------------|
| pin | Signal |
| 1 | Pt100 side 1 |
| 2 | Pt100 side 1 |
| 3 | Pt100 side 2 |
| 4 | Pt100 side 2 |

| Connector J21 to J28 | |
|----------------------|--------|
| pin | Signal |
| 1 | CMD |
| 2 | AGND |
| 3 | Signal |
| 4 | +3.3V |

| Connector J30 to J34 | |
|----------------------|--------|
| pin | Signal |
| 1 | +12V |
| 2 | CMD |
| 3 | GND |
| 4 | Signal |
| 5 | AGND |

| Connector J29, J48 | |
|--------------------|--------|
| pin | Signal |
| 1 | +24V |
| 2 | CMD |
| 3 | GND |

2.6.2. XENON500




| Connector J1 | |
|--------------|--------|
| pin | Signal |
| 1 | +24V |
| 2 | CMD |
| 3 | GND |

| Connector J2 | |
|--------------|---------|
| pin | Signal |
| 1 | Anode |
| 2 | GND |
| 3 | GND |
| 4 | Trigger |

XENON500 schematics 1/1
Release A

2.6.3. OUT-4-20-500




| Connector J1 | |
|--------------|--------|
| pin | Signal |
| 1 | GND |
| 2 | CS |
| 3 | DIN/ |
| 4 | SCLK/ |
| 5 | DOUT |
| 6 | +3.3V |
| 7 | 0VP |
| 8 | +24V |
| 9 | +12V |

| Connector J2 | |
|--------------|--------------------|
| pin | Signal |
| 1 | (+) 4-20 mA output |
| 2 | (-) 4-20 mA output |


OUT4-20-500 schematics 1/1
Release A

2.6.4. IN-4-20-500



IN4-20-500 schematics 1/1
Release A

2.6.5. RELAY500



| Connector J1 | |
|--------------|--------|
| pin | Signal |
| 1 | GND |
| 2 | CS |
| 3 | DIN/ |
| 4 | SCLK/ |
| 5 | DOUT |
| 6 | +3.3V |
| 7 | 0VP |
| 8 | +24V |
| 9 | +12V |

| Connector J2 | |
|--------------|------------|
| pin | Signal |
| 1 | NO contact |
| 2 | Common |
| 3 | NC contact |

| Connector J3 | |
|--------------|-----------------|
| pin | Signal |
| 1 | + 24V DC output |
| 2 | GND |

RELAY500 schematics 1/1
Release A

2.7. Modbus Addresses

| Category | Address in Decimal | Type | Description | Unit | Comment |
|-------------|--------------------|--|---|------|---------------------------------------|
| ZERO | 512 | Table of 16x6 intergers (year, month, day, hour, min, sec) | Last zeroing date | | For each channel |
| | 96 | Table of 16xIEEE754 float (32 bit) | Concentration of zero gas | ppm | For each channel |
| | 352 | IEEE754 float (32 bit) | Optical signal at 250 nm on last zero | mV | |
| | 128 | Table of 16xIEEE754 float (32 bit) | Zero drift | ppm | For each channel |
| CALIBRATION | 640 | Table of 16x6 intergers (year, month, day, hour, min, sec) | Last calibration date | | For each channel |
| | 160 | Table of 16xIEEE754 float (32 bit) | Concentration of standard gas | ppm | For each channel |
| | 192 | Table of 16xIEEE754 float (32 bit) | Optical signal at 250 nm on standard | mV | For each channel |
| | 224 | Table of 16xIEEE754 float (32 bit) | Difference (measurement minus standard) | ppm | For each channel |
| MEASUREMENT | 768 | Table of 16x6 intergers (year, month, day, hour, min, sec) | Last measurement date | | |
| | 64 | Table of 16xIEEE754 float (32 bit) | Optical signal at 250 nm on measurement | mV | For each channel |
| | 16 | Table of 16xIEEE754 float (32 bit) | Measurement | ppm | For each channel |
| | 48 | Table of 16xinteger (16 bit) | Error code | | 0=no error, refer to operating manual |

| Category | Address Decimal | Type | Description | Unit | Comment |
|------------------|--------------------|------------------------------------|---------------------------------------|---------|---------------------|
| MAIN PARAMETERS | 256 | Table of 16xIEEE754 float (32 bit) | Range | ppm | For each channel |
| | 288 | Table of 16xIEEE754 float (32 bit) | Calibration coefficient | | For each channel |
| | 320 | Table of 16xIEEE754 float (32 bit) | Offset value | ppm | For each channel |
| OTHER PARAMETERS | 354 | IEEE754 float (32 bit) | Pressure (relative) | hPa | |
| | 356 | IEEE754 float (32 bit) | Temperature | °C | |
| | 352 | IEEE754 float (32 bit) | Optical signal at 250 nm on last zero | mV | |
| | 896 | Integer (16 bits) | Automatic zero period | Minutes | |
| | 897 | Integer (16 bits) | Automatic calibration period | hours | |
| STATUS | 898 | Integer (16 bits) | Measurement | | Value = 1 |
| | 898 | Integer (16 bits) | Standby | | Value = 2 |
| | 898 | Integer (16 bits) | Zeroing | | Value = 3 |
| | 898 | Integer (16 bits) | Calibration | | Value = 4 |
| | 898 | Integer (16 bits) | Full system calibration | | Not applicable |
| | 898 | Integer (16 bits) | Backflush | | Value = 6 |
| | 898 | Integer (16 bits) | Maintenance | | Value = 7 |
| ALARMS | 899 | Integer (16 bits) | Analyser failure | | Value = 1 |
| | 899 | Integer (16 bits) | Light failure | | Value = 2 |
| | 899 | Integer (16 bits) | Range limit alarm | | Value = 3 |
| | 899 | Integer (16 bits) | Minimum range alarm | | Value = 4 |
| | 899 | Integer (16 bits) | Temperature failure | | Value = 5 |
| | 899 | Integer (16 bits) | Pressure failure | | Value = 6 |
| REMOTE CONTROL | 900 | Integer (16 bits) | Start zero | | Write 1, go back to |

| | | | | | |
|--|------------|---|-------------------------------|--|--|
| | | | | | zero when finished |
| | 901 | Integer (16 bits) | Start calibration | | Write 1, go back to zero when finished |
| | 902 | Integer (16 bits) | Start measurement | | Write 1, go back to zero when finished |
| | 903 | Integer (16 bits) | Stop measurements | | Write 1, go back to zero when finished |
| | 904 | Integer (16 bits) | Start full system calibration | | Not applicable |
| | 905 | Integer (16 bits) | Startbackflush | | Write 1, go back to zero when finished |
| | 906 | Table of 6xintergers (year, month, day, hour, min, sec) | Clock adjustment | | Any engaged cycle will be aborted |

From Software V1.14

3. Troubleshooting

3.1. General Troubleshooting



Disconnect the power cord before servicing!

| Symptoms | Checking / Origin |
|--|---|
| <p>The screen remains totally black after connecting the power cord.</p> <p>AND</p> <p>The red LED D1 on the DSP500 board is OFF.</p> | <ul style="list-style-type: none">- Check the power socket- Check J1 connector (mains input, high voltage!)- Check J2 connector on the DSP500 (mains input for the power supply, high voltage!)- Check J3 connector (24V output from the power supply)- Failure on the power supply of the DSP500 board |
| <p>The screen remains totally black after connecting the power cord.</p> <p>AND</p> <p>The red LED D1 on the DSP500 board is ON.</p> | <ul style="list-style-type: none">- Check the backlight connector of the screen J10.- Failure off the DSP500 board. |
| <p>The screen is lighted but nothing is displayed.</p> | <ul style="list-style-type: none">- Check the screen connector J8 on the rear of the DSP500 board- Failure off the DSP500 board. |

3.2. Measurements troubleshooting

| Symptoms | Origin |
|-------------------|--|
| Frozen value | <ul style="list-style-type: none">- Check the mode and select the <u>continuous</u> mode- A zeroing cycle is in progress, wait for the end of the cycle (< 1 min)- A automatic calibration cycle is in progress, wait the end of the cycle (<1 min) |
| Value is too low | <ul style="list-style-type: none">- Bad zeroing: check or redo the zero- Bad calibration: check the instrument with a standard- No flow rate: check the gas circulation |
| Value is too high | <ul style="list-style-type: none">- Bad calibration: check the instrument with a standard.- Internal temperature no stabilised, wait 4 hours after power on for full accuracy |
| Unstable value | <ul style="list-style-type: none">- Deposit or dirty on the optical parts (lens and/or windows), check the light level at 200 nm, must be typically around 200 mV- Interference from another gas: check the gas composition- Bad calibration (too sensitive): check with a standard. |

3.3. Measuring Errors for Parameters

| Error no | Signification | Origin / Remediation |
|----------|---|--|
| 1 | Gas circuit temperature too low (more that 10 °C bellow the set point) | <ul style="list-style-type: none"> - Wait for temperature stabilisation after power on, minimum 10 min on 230V AC. - Wong configuration: check the temperature setting screen. - Failure on the heating system or temperature probe. |
| 2 | Detector fault | <ul style="list-style-type: none"> - Check the spectrograph connection. - Failure on the spectrograph board. |
| 3 | The light level is too high on the range of wavelengths used for the considered gas | <ul style="list-style-type: none"> - Reduce the number of flashes in the lamp screen - Failure on the CCD500 or SPECTRO500 board (replace) |
| 4 | The light level is too low on the range of wavelengths used for the considered gas | <ul style="list-style-type: none"> - Deposits inside the gas flow cell: clean the windows (or mirrors for CEM500-L). Check also that the temperature setting is correct, normally 190°C (or 240°C for CEM500-L) - Deposits on the lens, clean the lens (in front of the lamp) with alcohol - Bad lamp alignment: check the alignment by adjusting the screw on the rear of the lamp holder - Failure on the xenon lamp circuit if no flashes are visible during the measurement: check the connection of the XENON500 board on the DSP500 board (the orange neon lamp N1 on the XENON500 board must always be on, if not replace the XENON500 board) and check the lamp connection on the XENON500 board |
| 5 | Pressure fault | <ul style="list-style-type: none"> - Check the pressure probe connection - Over pressure (>2 bar or > 2000 hPa) - Pressure probe failure |
| 6 | Flow alarm | <ul style="list-style-type: none"> - Value is superior to upper limit value - Value is lower than lower limit value - Check if alarm values are relevant - Check if gas is still flowing in the gas circuit |

4. General Specifications

| | |
|----------------------------------|---|
| <i>Sample temperature:</i> | 0 °C to 400 °C |
| <i>Sample pressure:</i> | 0 to 2 bar (2000 hPa or 30 psi) absolute pressure |
| <i>Outlet pressure:</i> | Atmospheric pressure (recommended) |
| <i>Sample contact materials:</i> | Stainless steel, quartz, PTFE, FFKM |
| <i>Zero inlet:</i> | Air or nitrogen (air recommended) |
| <i>Zero pressure:</i> | Without pump: 10 to 50 hPa above the atmospheric pressure With pump: atmospheric pressure |
| <i>Zero temperature:</i> | 0 °C to 400 °C (ambient temperature recommended) |
| <i>Sample Inlet/outlet:</i> | Stainless steel fittings (Swagelok) for external diameter 6.4 mm (1/4") |
| <i>Display:</i> | Colour TFT LCD, Size: 10.4", resolution: 640 x 480 pixels LED backlight with screen saver. Resistive touch screen |
| <i>Memory:</i> | 5000 records (up to 16 measurement channels) with date and time |
| <i>Communication:</i> | RS232 - MODBUS protocol RS485 - MODBUS protocol |
| <i>USB port:</i> | For USB memory keys, any format (FAT16, FAT32) Standard USB connector type A with IP68 protective cap Recorded measurement downloads (compatible with Excel®) Complete configuration backup/restore (proprietary format) Screen copy in BMP format (compatible with Windows®) Software |
| <i>Extensions:</i> | 12 internal sockets for input modules (logical input, 4-20 mA input), output modules (4-20 mA) or relays modules |
| <i>Outputs:</i> | Active 4-20 mA (optional), load 500 Ohm maxi, resolution 0.005 mA, Individual galvanic isolation Connection on removable screw terminals |
| <i>Relays (optional):</i> | Normally open (NO) and normally closed (NC) contacts Contact rating: 5A @ 277VAC/30VDC resistive Connection on removable screw terminals |

| | |
|--------------------------|---|
| <i>Power supply:</i> | 110-264 VAC / maxi 900 W / 50-60Hz (250 VA after stabilization) |
| <i>Operating limits:</i> | 0 to 40 °C |
| <i>Safety standard:</i> | IEC 61010-1, EN 61010-1 |
| <i>EMC standard:</i> | EN61326/A1/A2/A3, IEC61000-3-2, IEC61000-3-3, IEC61000-4-2, IEC61000-4-3, IEC61000-4-4, IEC61000-4-5, IEC61000-4-6, IEC61000-4-11 |
| <i>Enclosure:</i> | IP65 / Nema 4X, stainless steel 316L with painting |
| <i>Dimensions:</i> | 521 x 345 x 252.5 mm |
| <i>Weight:</i> | 30 kg approx. |
